

ADJUSTMENT INSTRUCTIONS

= FIND YOUR COMFORT LEVEL



BACK HEIGHT ADJUSTMENT

Lift the back to adjust height. Nine fixed positions offer up to 2" of range.



LUMBAR HEIGHT

Raise or lower the lumbar support to fit your lower back.



SEAT HEIGHT ADJUSTMENT

While seated, raise the right-side lever to adjust height.



SEAT DEPTH

Lift the left-side lever, slide the seat, then release to lock.



MECHANISM LOCK

Turn the knob clockwise to lock and counterclockwise to unlock.



NEED HELP WITH YOUR CHAIR?

Scan to contact BodyBilt Customer Service.

For help, call 800-364-5299.