
BodyBilt®



Aircelli Stretch Instructions



Aircelli Stretch Instructions



Lumbar

Lift chair back to adjust height.

Armrest Width Adjustment

Loosen knob and slide armrest in or out. Tighten knob to lock.

Backrest Angle

Lift the lever to adjust back, release the lever to lock.

Seat Height

Lift lever and hold while adjusting seat height. Release lever to set.

Seat Tilt

Lift lever to release tilt motion, push toward floor to lock.

Tilt Limiter

Turn knob to set the allowable forward angle for chair back.

www.BodyBilt.com



Arm Pad Adjustments

Side-to-Side Adjustment: Grasp ends of arm pad, slide left/right.

360° Rotation: Grasp front and back of metal plate beneath arm pad, lift and rotate to desired position/angle.

30° Pivot: Twist front of arm pad left/right 15°.

Arm Height

Lift and hold oval trigger to adjust height. Release to set.

Seat Depth Lever

Lift the lever and hold while sliding seat forward or back. Release lever to set.

Tilt Tension Adjuster

Turn knob clockwise to increase tilt tension, counterclockwise to loosen.

BodyBilt®