
BodyBilt®



Aircelli
Instructions

A decorative pattern of blue arrows pointing up and down, arranged in a grid-like fashion. The arrows are of varying lengths and are interspersed with small blue squares. The pattern is located on the right side of the page, extending from the top to the bottom.

Aircelli Instructions



Arm Pad Adjustments

Side-to-Side Adjustment: Grasp ends of arm pad, slide left/right.

360° Rotation: Grasp front and back of metal plate beneath arm pad, lift and rotate to your desired position and angle.

30° Pivot: Twist front of arm pad to the left 15° or right 15°.

Arm Height

Lift and hold oval trigger to adjust height. Release to set.

Tilt Tension Knob

Turn knob forward to tighten tilt tension; turn rearward to loosen tilt tension.

Seat Height Lever

Lift lever (behind and to left of tension knob) until tension is felt, and hold lever while adjusting seat height. Release lever to set.

Lumbar
Lift chair back to adjust height.

Armrest Width Adjustment

Loosen knob and slide armrest in or out. Tighten knob to lock.

Back Lock Knob

To lock tilt, recline in chair and turn knob rearward. To release, turn knob forward and lean back into chair until you hear the audible click.

Seat Depth Lever

Lift and hold lever (behind and to right of tilt locking knob) while sliding seat forward or back. Release lever to set.

