BodyBilt* Sola J2607 Instructions

Sola J2607 Instructions



Lumbar ⊢

Slide lumbar pad up/down to adjust.

Armrest Width

Adjustment ⊢

Loosen knob and slide armrest in or out. Tighten knob to lock.

Backrest Angle +

Lift the lever to adjust back, release the lever to lock

Seat Height⊢

Lift lever and hold while adjusting seat height.

Release lever to set

Tilt Limiter F

Turn knob to set the allowable forward angle for chair back.

Seat Tilt +

Lift lever to release tilt motion, push toward floor to lock.

Arm Pad Adjustments Side-to-Side Adjustment: Grasp ends of arm pad, slide left/right.

360° Rotation: Grasp front and back of metal plate beneath arm pad, lift and rotate to desired position/angle.

30° Pivot: Twist front of arm pad left/right 15°.

⊣ Arm Height

Lift and hold oval trigger to adjust height. Release to set.

→ Seat Depth Lever

Lift the lever and hold while sliding seat forward or back. Release lever to set.

Tilt Tension Adjuster

Turn knob clockwise to increase tilt tension, counterclockwise to loosen.

