


---



BodyBilt®



**Sola R2607**  
Instructions



# Sola R2607 Instructions



## Lumbar

Slide lumbar pad up or down to adjust.

## Armrest Width Adjustment

Loosen knob and slide armrest in or out. Tighten knob to lock.

## Backrest Angle

Turn knob forward to bring chair back forward, backward to increase backrest angle.

## Seat Tilt Tension

Pull handle out and turn knob forward to tighten tilt tension; turn rearward to loosen tilt tension.

## Seat Height Lever

Lift lever and hold while adjusting seat height. Release lever to set.

[www.BodyBilt.com](http://www.BodyBilt.com)



## Arm Pad Adjustments

**Side-to-Side Adjustment:** Grasp ends of arm pad, slide left/right.

**360° Rotation:** Grasp front and back of metal plate beneath arm pad, lift and rotate to desired position/angle.

**30° Pivot:** Twist front of arm pad left or right 15°.

## Arm Height

Lift and hold oval trigger to adjust height. Release to set.

## Seat Tilt Adjustment

Turn knob forward to release tilt motion, rearward to lock in position.

## Seat Depth Lever

Lift the lever and hold while sliding seat forward or back. Release lever to set.

BodyBilt®