


BodyBilt®



Midcelli & Midcelli Petite Instructions

J-Mechanism





Lumbar/Back Height

Lift back to adjust height. Five (5) fixed positions exist to permit a 2.5" range of back height/lumbar movement.



Arm Pad Adjustments

Side-to-Side: Grasp center of pad; slide left or right.
Pivot: Twist front of the arm pad to the left or to the right up to 20°.
Slide: Arm pad slides a total of 1" fore/aft from center.



Arm Height

Lift and hold the button near the front of the arm to raise and lower. Arm has five (5) fixed locking positions.



Armrest Width

Pad can be adjusted side to side. For greater width adjustment, loosen the knob and slide the armrest in or out underneath the seat, then tighten the knob.



Back Angle Control

While seated, lift the back lever on the right side to adjust the back, release the lever to lock.



Seat Height Lever

While seated, lift the second lever from the back on the right side and adjust the seat height. Release the lever to set the seat height.



Seat Tilt

While seated, lift the front lever to release tilt motion; push the lever toward the floor to lock tilt motion.



Seat Tilt Limiter

From a seated position, turn the Front Mechanical Tilt Stop knob forward to increase the seat's forward tilt. Turn the knob backward to decrease the seat's forward tilt.



Seat Depth

While seated, lift the lever on the left side of the seat and hold while sliding seat forward or back. Release the lever to set.



Tilt Tension Adjuster

Turn the Tilt Tension knob clockwise to increase tilt tension; counterclockwise to loosen.

BodyBilt®



ErgoGenesis Workplace Solutions, LLC

Manufacturer of BodyBilt Seating
& Ergonomic Workplace Solutions

W: www.BodyBilt.com

P: 800.364.5299

E: Customer-Service@ErgoGenesis.com

BB200102_2.00