


BodyBilt®



Midcelli Instructions

A-Mechanism





Lumbar/Back Height

Lift back to adjust height. Five (5) fixed positions exist to permit a 2.5" range of back height/lumbar movement.



Arm Pad Adjustments

Side-to-Side: Grasp center of pad; slide left or right.
Pivot: Twist front of the arm pad to the left or to the right up to 20°.
Slide: Arm pad slides a total of 1" fore/aft from center.



Arm Height

Lift and hold the button near the front of the arm to raise and lower. Arm has five (5) fixed locking positions.



Armrest Width

Pad can be adjusted side to side. For greater width adjustment, loosen the knob and slide the armrest in or out underneath the seat, then tighten the knob.



Tilt Tension Knob

Turn the knob on the right side (when seated) forward to tighten the tilt tension. Turn the knob rearward to loosen the tilt tension.



Back Angle Control

To rock and/or lock to preferred reclining position, turn the left knob (when seated) rearward. To release, turn knob forward and lean back into the Midcelli until you hear a click. Five (5) locking positions exist for your comfort.



Seat Height Lever

Without weight on the seat, raise the front lever on the right side (when seated) to attain your desired height.



Seat Depth Lever

Lift lever on the left side (when seated) while sliding the seat forward or back. 2.5" range of slide.

BodyBilt®



ErgoGenesis Workplace Solutions, LLC

Manufacturer of BodyBilt Seating
& Ergonomic Workplace Solutions

W: www.BodyBilt.com

P: 800.364.5299

E: Customer-Service@ErgoGenesis.com